
## Symbols of Audio devices [ Go to Website ]

Speaker / Loudspeaker	Speaker with divergence grille	Piezzo reproductor Buzzer	Interphone / Intercom
Piezzo reproductor Buzzer	——————————————————————————————————————	BZ Buzzer	Electric horn Horn loudspeaker
Claxon electric horn	Electric whistle	Electric siren Electronic siren	Electric doorbell
Musical bell	Plectric doorbell	Electric doorbell	Electric doorbell
Electric bell	Bright electric bell	Buzzer	Gong
Buzzer	Electric carrack	Hearing aid / Headphone Earspeakers / Earphones	Single headphones

## Symbols of Audio devices [ Go to Website ]

$\preceq$	<u></u>	Mono headphones	q p	Stereo headphones	<u>-</u> 6	Stereo headphones	d b	Stereo headphones
	=()	Microphone Generic symbols	=\frac{1}{2}	Directional microphone Unidirectional	$\Diamond$	Microphone Generic symbol		Carbon microphone
	<b>‡</b>	Capacitor microphone Condenser microphone	(co)	Stereo microphone	<b>⊝</b> =	Electret microphone Electret condenser	-olo-	<ul> <li>Push-pull microphone</li> </ul>
	þ	Phono cartridge Phono Pick-Up Pickup turntable stylus Generic symbol	=Q	Phono cartridge Turntable stylus	$\Diamond$	Dynamic phono cartridge Magnetic cartridges	<b>©</b>	Piezoelectric phono cartridge
	$\Leftrightarrow$	Stereo phono cartridge	Щ	Magnetic head Generic symbol	4	Magnetic head reader Playback	#	Recording head
	<del>М</del>	Magnetic erase head	#	Magnetic read-write head		Drum head Rotating head Heads for read, write and erase		> Magnetic head



4/4

## Symbols of Audio devices (Sound Representation Symbols) [ Go to Website ]

